

Temperature Kiosk

Jiushide Investment Technology CO., LTD

Intelligent access control system self-built
server user manual

EN. 20200529



JIUSHIDE

www.safetyproductsppe.com

Rights Reserved

Shenzhen Jiushide Investment Technology CO., LTD keeps all rights

RESERVED.

Without a written permission, no unit and individual can copy the contents of this document in part or whole, or transmit it in any form.

NOTE

This document may be updated irregularly for upgrade version or other reasons. Unless some additional agreements, there is no guarantee for any explicitly and implicitly made by statements, information or suggestions in this document.

Table content

1. Build environment.....	- 1 -
2. Install package software.....	- 1 -

1. Build environment

We recommend to use Google Chrome, Firefox etc., IE browser is not supported.

2. Install package software

Notice: When setting up the server, make sure that the local computer has exited all relevant anti-virus software, otherwise it will cause the installation software to fail to download.


1. Download server installation package(please contact Lango staff to



obtain),double-click the installation package, follow the guided steps to install step by step to the default root directory(notice:other disks can be selected, but Chinese、space、special characters should not appear in the installation path), then generate the folder after installation.




2. Select and double-click. A tomcat window will pop up, do not close the window until it appears “重启 MQTT 连接成功” ,like this:



Minimize the window, open Google Chrome, and enter the IP address

- If the interface cannot be accessed, please check whether the anti-virus software is completely closed; or contact the service provider for help.
- If you do not know the local IP address, please enter the initial IP:127.0.0.1 to enter the login page.



Please change the IP address in time, this default IP address only allow this computer to operate the system.

- If you know the IP address clearly, please enter the corresponding address and

enter to the login page.

3. After login the system, click settings-authorized points-add, contact service provider to obtain license file, after the system detects the authorization environment, points will be authorized successfully.

